

1-2200 Series Replaceable Single-Wall Spill Container



- ◆ Designed for proposed 2014 EPA Regulations and beyond
- ◆ Prepares you for future compliance
- ◆ Innovative Snowplow Ring-less, Liquid-Tight Cover
- ◆ Easy access for overfill prevention valve testing and inspection
- ◆ Replaceable bucket without breaking concrete

FEATURES:

- Flange Adaptor allows easy removal of fill/vapor adaptor and access to the drop tube and overfill valve
- Innovative Snowplow Ring-less, Liquid-Tight Cover Design with Integrated Lift Handle
- Removable Bellows and Ring



The NEW 1-2200 Series Replaceable Single-Wall Spill Container

Replace Bellows in 3 Easy Steps



Remove Upper Bolts and Ring



Remove Lower Bolts and Ring and Remove Bellows



Replace Bellows, Reinstall Upper and Lower Rings

No Need to Remove Base in order to Replace Bellows

Ordering Specifications

1-2200 Series Spill Container Models

Part Number	Description
1C-2200D	Single-Wall, Field Replaceable Spill Container with Drain Valve
1C-2200P	Single-Wall, Field Replaceable Spill Container with Drain Plug
1-3100-TOOL	Installation Tool, Used for Edge and 1-2200 Spill Containers


Liquid-Tight Cover

Special Cover and Ring Design
Seals Out Water and Debris

Eliminates Need for
Snow Plow Ring –
Flush with Finish Grade

Proven “Bubble Seal”

Removable Compression Ring



1-2200 Series Replacement Parts

	Part/Kit Number	Description
1	207235	Cover
2	H12229M	Cover Seal
3	201739	Flange Adapter
4	201692	Flange Adapter O-Ring
5	1DK-2100-EVR	Drain valve sub assembly
6	1DP-2100	Drain Plug Kit
7	208951	Upper Ring Replacement Kit (includes; o-ring and hardware)
8	207243	Upper Ring O-Ring
9	208952	Bellows Replacement Kit (includes; o-rings, split rings, and hardware)
10	207212	Lower Split Ring, Each (2 required per spill container)
11	207211	Lower Bellows O-ring
	208197	Installation Instructions

